

## A FLEXIBLE SPRAY WAND FOR SELECT NU-CALGON AEROSOLS

- Specially developed 27 inch length, reusable flexible spray wand
- Provides precision spray in tight spaces
- For tough-to-reach locations
- Use Talon with:
  - **Evap Foam No Rinse**  
*For cleaning air conditioner evaporators*
  - **Blackhawk**  
*For cleaning refrigeration coils in food processing areas*
  - **PenetrateHD**  
*For applying penetrating lubricant in tough-to-reach locations*
  - **Evap-Fresh No Rinse**  
*For disinfecting and cleaning air conditioner evaporators*

### Description

The Talon Flexible Aerosol Wand is a specially developed 27 inch length accessory to be used exclusively with Nu-Calgon's Evap Foam No Rinse, Evap-Fresh No Rinse, Blackhawk and PenetrateHD aerosol products. The device provides precision spraying in tough-to-reach locations, especially when injecting product into a small opening. The reusable Talon is highly flexible yet has shape memory when navigating around equipment components or cabinetry to spray.

### Application

The Talon is developed for Nu-Calgon's Evap Foam No Rinse and Blackhawk aerosol-based coil cleaners or applying Penetrate HD, a super penetrating lubricant, in tough-to-reach locations. The Talon Flexible Aerosol Wand provides precision spray control in field situations where it's simply difficult to fit/orientate the aerosol canister by itself around existing obstructions. In addition, with better spray control in tough-to-reach locations, there is less unwanted product waste on adjacent surfaces. The Talon is a must have service tool!

### Packaging

1 each **4776-0**

## Aerosol Products

### Talon



### Directions for Use

This product must be used in accordance to the following directions by HVAC/R professionals only.

1. Wear protective eyewear and gloves.
2. Remove existing aerosol tip from the canister. Shake can well.
3. **IMPORTANT:** In a safe location, point Talon tip toward ground and assemble onto canister. A momentary discharge will occur.
4. Always remove Talon from aerosol canister when job is complete. Never transport while Talon is assembled to canister.

### Talon is Great for:

